



AVA MASTER SERIES

## **Hose replacement**

### **2018-19 Model**

**Needed tools:**

You will need a short torx T25 screwdriver and pliers for C-clips or another tool to remove such a clip.

1



**NOTE! Disconnect all power before starting service!**

- 1) Pull out all the hose from the drum.
- 2) Use pliers to remove the C-clip that holds the swivel to the drum.
- 3) Unscrew the two screws that hold the hose cover in place.
- 4) Then pull the metal swivel off the brass shaft.



# 2

- 1) Before mounting the hose, check that the o-rings are undamaged and are well lubricated.
- 2) Insert the new swivel onto the shaft and lock with the supplied E-clip. (This requires no special pliers, it just needs to be pressed into place).
- 3) Feel free to test the machine before replacing the cover you removed in the previous step.
- 4) Fit the cover that holds the hose.

