



AVA MASTER SERIES

Hose replacement

2020 Model

Needed tools:

You will need a short torx T25 screwdriver and pliers for C-clips or another tool to remove such a clip.

1



NOTE! Disconnect all power before starting service!

Remove the hose:

1. Pull out all the hose from the drum.
2. Unscrew the two screws holding the hose cover in place (1)
3. Remove the cover and set it aside.
4. Press down the bracket on the brass coupling and pull out the hose (2)

Assembly:

1. Press down the metal bracket and push the hose into place.
2. Pull the hose to check that it fits snugly (3).
3. Place the cover over the hose and make sure it corresponds to the screw holes on the drum.
4. Replace the screws that secure the cover (4).

